1"SQ.DR. IMPACT WRENCH

EXPLODED VIEW

SP-1193GEP-2



PARTS LIST

Index No.	Parts No.	Description	Qty. Per tool
1	193GEP-01	Oil Seal	1
2	193GEP-02	Hammer Case (Incl:1,3)	1
3	193GEP-03	Fixed Bush	1
4	193GEP-04	Hex. Socket Bolt	4
5	193GEP-05	Spring Washer	8
6	193GEP-06	D-Type Handle	1
7	193GEP-07	Hex. Socket Bolt	4
8	193GEP-08	Spring Washer	4
9	193GEP-09	Side Plate	1
10	193GEP-10	Retainer Ring	1
11	193GEP-11	O-Ring	1
12	193GEP-12	Anvil (2" Short)	1
13	193GEP-13	Hammer	1
14	193GEP-14	Cam	1
15	193GEP-15	Hammer Frame	1
16	193GEP-16	Hammer Case Packing	1
17	193GEP-17	Motor Housing (Incl:17,41)	1
18	193GEP-18	Ball Bearing	1
19	193GEP-19	Front End Plate	1
20	193GEP-20	Cylinder	1
21	193GEP-21	Spring Pin	2
22	193GEP-22	Rotor	1
23	193GEP-23	Rotor Blade	6
24	193GEP-24	Rear End Plate	1
25	193GEP-25	Spring Pin	1
26	193GEP-26	Ball Bearing	1
27	193GEP-27	Motor Case Packing	1
28	193GEP-28	Screw	1
29	193GEP-29	Trigger	1
30	193GEP-30	Throttle Pin	1
31	193GEP-31	Throttle Bushing	1

Index No.	Parts No.	Description	Qty. Per tool
32	193GEP-32	Screw	2
33	193GEP-33	Throttle Cover	1
34	193GEP-34	Valve Seat	1
35	193GEP-35	Valve	1
36	193GEP-36	Throttle Spring	1
37	193GEP-37	Deflector	1
38	193GEP-38	O-Ring	1
39	193GEP-39	Inlet Bushing	1
40	193GEP-40	Screw	1
41	193GEP-41	Adjust Valve Bushing	1
42	193GEP-42	Spring Washer	4
43	193GEP-43	Nut	4
44	193GEP-44	Snap Ring	1
45	193GEP-45	Housing Cover	1
46	193GEP-46	O-Ring	1
47	193GEP-47	Adjust Valve	1
48	193GEP-48	Spring	1
49	193GEP-49	Steel Ball	1
50	193GEP-50	Hex. Socket Bolt	4
51	193GEP-51	Housing Band	1
52	193GEP-52	Housing Band	1

The types and specifications may be changed without notice.